

**SAMPLE PROJECT
SCHEDULE OF TERMINATIONS**

CABLE #	SOURCE	SOURCE LOCATION	DESTINATION	DESTINATION LOCATION	WIRE TYPE
A1 - A2	FLOOR BOX 1	PLATFORM	MIXER CHANNELS 1 - 2	FOH	1 - 454 EACH
B1 - B2	FLOOR BOX 2	PLATFORM	MIXER CHANNELS 3 - 4	FOH	1 - 454 EACH
C1 - C2	FLOOR BOX 3	PLATFORM	MIXER CHANNELS 5 - 6	FOH	1 - 454 EACH
D1 - D5	FLOOR BOX 4	DRUM ROOM	MIXER CHANNELS 7 - 11	FOH	1 - 454 EACH
E1 - E2	FLOOR BOX 5	PLATFORM	MIXER CHANNELS 12 - 13	FOH	2 - 454 EACH
G1 - G2	FLOOR BOX 6	PLATFORM	MIXER CHANNELS 14 - 15	FOH	3 - 454 EACH
G3 - G4	LESLIE ROOM	LESLIE ROOM	MIXER CHANNELS 16 - 17	FOH	4 - 454 EACH
E1 - E3	CHOIR MIC JACKS ON MODESTY WALL	PLATFORM	MIXER CHANNELS 18 - 20	FOH	5 - 454 EACH
E4-E6	SUSPENDE CHOIR MICS, BAPTISTRY MIC	PLATFORM, BAPTISTRY	MIXER CHANNELS 21 - 23	FOH	6 - 454 EACH
F1-F4	WIRELESS RECEIVERS	FOH	MIXER CHANNELS 24-27	FOH	XLR:XLR
F5-F8	CD-A500 CASS., CD OUT, VIDEO OUT	FOH	MIXER CHANNEL 28-32	FOH	RCA TO 1/4" COMMERCIAL CABLE
F9	MIXER AUX 4 OUT	FOH	EXTRON MDA-5A-RCA	FOH	1/4" MONO SPLIT TO STEREO RCA COMMERCIAL CABLE
F10	COMPUTER AUDIO	FOH	SWITCHER-SCALER	FOH	COMMERCIAL MINI-TRS: MINI-TRS
F11	COMPUTER VIDEO	FOH	VGA SPLITTER	FOH	COMMERCIAL VGA:VGA
F12	VGA SPLITTER #1	FOH	MONITOR	FOH	COMMERCIAL VGA:VGA
F13	VGA SPLITTER #1	FOH	SWITCHER-SCALER	FOH	COMMERCIAL VGA:VGA
F14	DVD PLAYER VIDEO	FOH	SWITCHER-SCALER	FOH	RCA
F15-F18	CAMERA BREAKOUT BOX	FOH	MARSHALL MONITOR	FOH	RCA
F19-22	MARSHALL MONITOR	FOH	EDIROL V4 MIXER	FOH	RCA
F23	EDIROL V4 MIXER	FOH	SWITCHER-SCALER	FOH	RCA
F24	EDIROL V4 MIXER	FOH	DVD RECORDER	FOH	RCA
F25	SWITCHER-SCALER	FOH	VGA SPLITTER #2	FOH	COMMERCIAL VGA:VGA
F26	SWITCHER-SCALER	FOH	DOWNSCALER	FOH	COMMERCIAL VGA:VGA
F27	DOWNSCALER	FOH	VIDEO MODULATOR	FOH	COMMERCIAL BNC:F
F28	SWITCHER-SCALER AUDIO OUT	FOH	MIXER INPUT 32	FOH	XLR TO STRIPPED/TINNED
F29-F30	VGA SPLITTER #2	FOH	GEFEN XMTRS	FOH	COMMERCIAL VGA:VGA
F31	EXTRON MDA-5A-RCA	FOH	CD-RW900	FOH	COMMERCIAL STEREO RCA
F32	EXTRON MDA-5A-RCA	FOH	VIDEO MODULATOR	FOH	COMMERCIAL STEREO RCA
F33	EXTRON MDA-5A-RCA	FOH	DVD RECORDER	FOH	COMMERCIAL STEREO RCA
FP1	KSM27 MIC	PRODUCTION ROOM	PROD. MIXER INPUT 1	PROD. DESK	XLR:XLR
FP2-FP5	TASCAM CD-A500	PROD. DESK	PROD. MIXER INPUT 13/14, 15/16	PROD. DESK	RCA TO 1/4" COMMERCIAL CABLE
FP6-FP7	PROD. MIXER CR L, R OUT	PROD. DESK	POWERED MONITORS	PROD. DESK	XLR:XLR
FP8-FP9	PROD. MIXER REC L, R OUT	PROD. DESK	TASCAM CD-RW900	PROD. DESK	STEREO RCA
H1-H4	POWER SEQUENCER OUT	FOH	POWER RELAYS	AMPLIFIER RACK	2 - 454 EACH
H5-H6	IR TRANSMITTER	FOH	IR EXTENDER RECEIVER	PROJECTORS 1 & 2	3 - 454 EACH
H7-H10	MAIN MIXER MONO, AUX 1,2,3 OUT	FOH	BIAMP NEXIA	AMPLIFIER RACK	4 - 454 EACH
H11-H12	LVC SCREEN CONTROLS	FOH	SCREENS	SCREEN 1 OVER CHOIR; SCREEN 2 OVER MAIN SANC. DOOR	1 - 454 EACH
H13-H14	MAIN MIXER L, R OUT	FOH	PROD. MIXER INPUT 11-12	PROD. DESK	
J1	VIDEO MODULATOR	FOH	TV MONITOR 1	NURSERY	RG6 COAX WITH F CONNECTORS
J2	TV MONITOR 1	NURSERY	PLASMA	NARTHEX	RG6 COAX WITH F CONNECTORS
J3	PLASMA	NARTHEX	TV MONITOR 2	CLERK'S OFFICE	RG6 COAX WITH F CONNECTORS
J4	TV MONITOR 2	CLERK'S OFFICE	TV MONITOR 3	PASTOR'S OFFICE	RG6 COAX WITH F CONNECTORS
J5	TV MONITOR 3	PASTOR'S OFFICE	TV MONITOR 4	ASSOC. MINISTER'S OFFICE	RG6 COAX WITH F CONNECTORS
J6	TV MONITOR 4	ASSOC. MINISTER'S OFFICE	PLASMA	CONFERENCE ROOM	RG6 COAX WITH F CONNECTORS
J7	TV MONITOR 5	CONFERENCE ROOM	PLASMA	BREEZEWAY	RG6 COAX WITH F CONNECTORS
J8	PLASMA	BREEZEWAY	TV MONITOR 5	CHOIR OVERFLOW ROOM	RG6 COAX WITH F CONNECTORS
K1	FLOOR BOX 1 GEFEN XMTR	FOH	GEFEN RECEIVER	FOH	CAT. 5
K2	PTZ CAMERA	CAMERA LOCATION 1	CAMERA BREAKOUT BOX	FOH	CAT. 5
K3	PTZ CAMERA	CAMERA LOCATION 2	CAMERA BREAKOUT BOX	FOH	CAT. 5
K4	PTZ CAMERA	CAMERA LOCATION 3	CAMERA BREAKOUT BOX	FOH	CAT. 5
K5	PTZ CAMERA	CAMERA LOCATION 4	CAMERA BREAKOUT BOX	FOH	CAT. 5
K6	GEFEN TRANSMITTER	FOH	GEFEN RECEIVER	PROJECTOR 2 ABOVE PLATFORM	CAT. 5
K7	GEFEN TRANSMITTER	FOH	GEFEN RECEIVER	PROJECTOR 1 REAR SANC. CEILING	CAT. 5
R1-R2	BIAMP NEXIA	AMPLIFIER RACK	CTS2000 UNIT A INPUTS 1,2	AMPLIFIER RACK	454
R3-R4	BIAMP NEXIA	AMPLIFIER RACK	CTS3000 INPUTS 1, 2	AMPLIFIER RACK	454
R4-R5	BIAMP NEXIA	AMPLIFIER RACK	CTS2000, UNIT B INPUTS 1, 2	AMPLIFIER RACK	454
R6-R7	BIAMP NEXIA	AMPLIFIER RACK	CTS2000, UNIT C, INPUTS 1,2	AMPLIFIER RACK	454
R8	BIAMP NEXIA	AMPLIFIER RACK	OPEN FUTURE BROADCAST A	AMPLIFIER RACK	454
S1	CTS2000, UNIT A OUTPUT 1	AMPLIFIER RACK	MAIN SPEAKERS 1, 2	ABOVE PLATFORM	227
S2	CTS2000, UNIT A OUTPUT 2	AMPLIFIER RACK	MAIN SPEAKER 3	ABOVE PLATFORM	227
S3	CTS3000 INPUT (BRIDGED)	AMPLIFIER RACK	SUBWOOFER	UNDER PLATFORM	227
S4	CTS2000, UNIT B INPUT 1	AMPLIFIER RACK	CEILING SPEAKERS (DAISY CHAIN)	NARTHEX (2), NURSERY (2), PASTOR, CLERK, ASSOCIATE, LIBRARY, CONF. ROOM	225
S5	CTS2000, UNIT B INPUT 2	AMPLIFIER RACK	CHOIR SPEAKER	ABOVE PLATFORM	227
S6	CTS2000, UNIT C INPUT 1	AMPLIFIER RACK	PASTOR MONITOR JACKS	FLOOR BOX 1,3 ON PLATFORM	227
S7	CTS2000, UNIT C INPUT 2	AMPLIFIER RACK	BAND MONITOR JACKS	FLOOR BOX2 ON PLATFORM & FB4 IN DRUM ROOM	227
V1-V2	SWITCHER-SCALER	FOH	GEFEN TRANSMITTER	FOH	1 - 227 EACH
V3-V4	GEFEN RECEIVER	PROJECTOR LOCATION	PROJECTOR	PROJECTOR LOCATION	COMMERCIAL VGA:VGA

FOH to platform		DRUM ROOM TO FOH			
22	454	FB'S, CHR, MICS,	6	454	FB4
1	CAT. 5	FLOOR BOX 2			
FOH TO AMPLIFIER RACK		LESLIE ROOM TO FOH			
8	454	signal & power control	2	454	FB5
AMPLIFIER RACK TO NURSERY		NARTHEX TO CLERK'S OFFICE			
1	225	CEILING SPEAKER	1	225	CEILING SPEAKER
AMPLIFIER RACK TO ABOVE PLATFORM		LIBRARY TO CONF. ROOM			
3	227	MAIN 1,2; MAIN 3; CHOIR	1	225	CEILING SPEAKER
FOH TO NURSERY		AMPLIFIER RACK TO DRUM ROOM			
1	RG6 COAX	TV	1	227	FLOOR BOX 4
AMPLIFIER RACK TO UNDER PLATFORM		FOH TO PROD. ROOM			
1	227	SUBWOOFER	2	454	MAIN MIX L, R
1	227	FLOOR BOX 1, 3			
1	227	FLOOR BOX 2			
CLERK'S OFFICE TO PASTOR'S OFFICE		CAMERAS TO FOH			
1	225	CEILING SPEAKER	4	CAT. 5	VIDEO, POWER
1	RG6 COAX	TV	1	225	CEILING SPEAKER
NURSERY TO NARTHEX		NARTHEX TO CLERK'S OFFICE			
1	225	CEILING SPEAKER	1	RG6 COAX	TV
1	RG6 COAX	PLASMA	CONFERENCE ROOM TO BREEZEWAY		
PASTOR OFFICE TO ASSOC. OFC.		FOH TO ABOVE PLATFORM			
1	225	CEILING SPEAKER	2	454	SUSP. CHOIR
1	RG6 COAX	TV	FOH TO BAPTISTRY CEILING		
1	RG6 COAX	TV	1	454	BAPTISTRY MIC
ASSOC. OFC. TO LIBRARY		AMONG FLOOR BOXES			
1	225	CEILING SPEAKER	1	227	FB1 TO FB3
FOH TO PROJECTORS ABOVE PLTFM		FOH TO SCREEN ABOVE PLTFM			
2	CAT. 5	SIGNAL	1	454	CONTROL
2	454	IR EXTRD.	FOH TO SCREEN REAR CEILING		
CEILING TO WALL NURSERY, PASTOR, CLERK, ASSOCIATE, LIBRARY, NARTHEX, CONF. ROOM		1		454	CONTROL
1 EACH	225	VOL. CONTROL			

Notes:

Cable prefixes:

A-G, H -- MIC/CONTROL CABLE/454

F -- CABLES WITHIN FOH RACK

FP -- PROD. ROOM RACK

R -- CABLES WITHIN AMP RACK

S -- SPEAKER CABLES/227

V -- VGA CABLES

K -- CAT.5

Color Codes: (per EIA standard)

1 -- brown

2 -- red

3 -- orange

4 -- yellow

5 -- green

6 -- blue

